

COMMON HF DIGITAL FREQUENCIES

BAND	RTTY/ PACTOR	PSK31	MFSK/ THROB	MT63	HELL	SSTV	FAX	PACKET
160M	1600- 1840	1838	1838	1822, 1838.15				
80M	3580- 3620	3580	3580	3580.15, 3590, 3635	3575, 3580, 3559	3730, 3845	3730	3620, 3620.9, 3623.9, 3627.9, 3635, 3638.9
40M	7070, 7100	7070, 7035	7037	7035.15, 7037	7030, 7035, 7037, 7040	7171		7068.9, 7070.9, 7071.9, 7072.9, 7073.9, 7076.9
30M	10130- 10140	10140	10147	10140.15, 10145	10135, 10137, 10145			10124.9, 10125.9, 10126.9, 10133.9, 10136.9, 10140, 10150
20M	14070- 14100	14070	14080	14106.3, 14109.3, 14114	14063, 14064, 14070	14227, 14230, 14233	14227	14062.9, 14072.9, 14073.9, 14074.9, 14075.9, 14076.9, 14095, 14099.5
17M	18100- 18105	18100	18105	18105, 1800.15	18100, 18105			18101.9, 18105, 18107.9, 18110
15M	21070- 21100	21080	21080	21130	21070	21340, 21355	21335	21072.9, 21100, 21110
12M	24920- 24925	24920	24929	24925				24925, 24930
10M	28070- 28150	28070, 28120	28080	28130	28063, 28070, 28100, 28110, 28120	28675, 28680	28675	

FREQUENCIES IN KHZ